

Step-By-Step Guide

Diamante Rivets

What you need:

- Diamante Rivets
- Acrylic Diamante Rivets Die Set
- The Green Machine



Step one:

Place the base of your Diamante Die Set into the bottom of your Green Machine and drop the Diamante Rivet in face down. Screw the top die in above and place the backing in, with the smooth edge facing up.



Step two:

Place your fabric inbetween your dies and slowly but firmly press your Green Machine handle down to secure.

And you're done!

This is a super easy fixing to use as you only need the one die. No hole is needed due to the serrated edge of the post which pierces through the fabric.

Please note that these are a decorative fixing rather than functional. It is advised not to use them on parts of your make that bare weight!