

Step-By-Step Guide

Snap Poppers

What you need:

- Snap Poppers
- Snap Poppers Die Set
- The Green Machine

In the same size



Step one:

Place the base of your Snap Poppers Die Set into the bottom of your Green Machine lay a pronged ring around the centre pin with the spikes facing up. Screw the top die in above and place the stud in facing up.

Step two:

Place your fabric in between your dies and slowly but firmly press down the handle of your Green Machine.

Step three:

Place another pronged ring onto the base die, again with the spikes facing up. Then push your socket into the top die, with the front facing up. Place your fabric in between your dies and slowly but firmly press down the handle of your Green Machine.

You will not need to cut any holes to place snap poppers as the prongs will pierce through the fabric themselves. The pronged rings will be on show of your design so keep this in mind!

(Close up of the socket)



Front



Back